



Model No. G-Pure-25W



# User Manual Air Purifier



READ AND SAVE THESE INSTRUCTIONS  
INSTRUCTION MANUAL AND WARRANTY INFORMATION



Model No. G-Pure-25W

## IMPORTANT SAFETY INSTRUCTIONS:

IN ORDER TO AVOID ANY DAMAGE TO YOU, OTHERS, OR PROPERTY, PLEASE FOLLOW THE FOLLOWING SAFETY PRECAUTIONS:

If the power cord or unit does not work, contact Greenlite customer service immediately.

READ ALL INSTRUCTIONS BEFORE USING.

### CAUTION – READ THE RULES FOR SAFE OPERATION AND INSTRUCTIONS CAREFULLY.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Indoor and household use only.
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
- Please use the original filter provided by the factory. In case of other filters, the best results cannot be achieved.
- DO NOT insert the fingers or objects into the air inlets or air outlets to prevent the product from physical damages or malfunction.
- Please unplug the power cord immediately and contact the service center in time when the appliance suffers abnormal sound or burnt smell or smoke.
- DO NOT block the air inlets/outlets of the appliance with any item.
- This appliance cannot replace natural ventilation and other appliances like vacuum cleaner, kitchen ventilator, etc.
- When the appliance is working, it must be placed on a dry, flat and stable floor, with at least 30 cm space reserved around it.
- The mist produced by the ultrasonic humidifier may affect the PM2.5 detection of this appliance, and both should maintain a certain distance.

### WARNING

- To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
- DO NOT place other items on top of the appliance, and forbid sitting or standing on this appliance.
- DO NOT spray flammable substances near the appliance; DO NOT spray water directly on the appliance or use chemical cleaners like alcohol or hydrochloric acid, etc.; DO NOT place water containers, medicines, or flammable materials on the appliance.
- DO NOT put it in a place with direct sunlight.
- To prevent electromagnetic disturbance, the appliance must keep a certain distance from the TV, radio, microwave oven and others.
- DO NOT disassemble or modify this appliance without authorization to avoid accidents.
- DO NOT pull the adapter cable to move the appliance. The appliance is only to be used with the power supply unit provided with the appliance.
- To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
- DO NOT operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- DO NOT run cord under carpeting. DO NOT cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.



## Model No. G-Pure-25W

If there is a fuse with a plug:

-This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

-Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

-This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

-To reduce the risk of fire, electric shock or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g. parts made at home using a 3D printer)


# SAVE THESE IMPORTANT INSTRUCTIONS FOR EASY REFERENCE.

Model No. G-Pure-25W

## TECHNICAL DATA

- Voltage: 120V~ 0.2A 60 Hz
- Power Rating: 25W
- Noise level: 40-60 dB(A)
- Room size: up to 108 sq. ft.
- Unit dimensions: 7.5"W x 7.5"D x 12.2"H
- Unit weight: 4.62 lbs.


## PRODUCT INFORMATION




Model No. G-Pure-25W

## INSTALLATION STEPS


1. Remove the HEPA filter integrated with the base. (Rotate the base clockwise to tighten, and rotate counterclockwise to remove)




2. Rotate the base counter-clockwise.




3. Remove the protective film of the filter assembly.



4. Install the HEPA filter. Rotate the base clockwise to tighten, and rotate counter-clockwise to remove.




5. Plug power supply.










Model No. G-Pure-25W

## PRODUCT OPERATION

### Control Panel Operation and Display



#	Icons	Function description
1	 On/standby button	Press this key to turn the machine on/off.
2	 Timing button	In the power-on state, press the "⌚" button to set the schedule power off time in the following sequence: 2h→4h→6h→Cancel→2h. In the power-on state, press and hold the "⌚" button to reset the working time of the filter.
3	 Fan speed button	Press this key to select high, medium or low fan speed.
4	 Fan speed: High	This indicator light is on when the fan speed level is high.
5	 Fan speed: Medium	This indicator light is on when the fan speed level is medium.
6	 Fan speed: Low	The indicator light is on when the fan speed level is low.
7	<b>2h</b> Timing 2 hours	In the power-on state, the indicator light turns on when the schedule power off time is set to 2 hours or 6 hours.
8	<b>4h</b> Timing 4 hours	In the power-on state, the indicator light turns on when the schedule power off time is set to 4 hours or 6 hours.
9	 HEPA filter replacement prompt	When this light is on, the filter needs to be replaced. After the filter is replaced and installed, press and hold the "⌚" button in the power-on state to reset the working time of the filter, and the indicator light will turn off.


Model No. G-Pure-25W

## TEST RUN

### NOTE:


- In case of continuous electricity, enter the working mode before the standby state, after each power on.
- The appliance is connected to the power again after unexpected power outage (when the power is off or the power cord is unplugged during normal operation), and then restores to the working state before the power outage.

1. Remove the protective film of the filter assembly.



2. Install the filter.

(Rotate the base clockwise to tighten, and rotate counterclockwise to remove)





3. Preparation

Power on for the first time, the control panel flashes for 1s, and then the screen is turned off. The whole appliance is in the standby state.

4. On/standby

Press on/standby button.



3. Working State

The purifier is powered on for the first time and then enters the medium speed mode.



Model No. G-Pure-25W


## CLEANING AND MAINTENANCE

### NOTE:

Be sure to turn the air purifier off before any maintenance and cut off the power.


### Cleaning the Air Purifier

Wipe the body with a soft towel.



### Air Outlet Grill


Vacuum up dust with a vacuum cleaner or wipe it with a cloth.




### Cleaning the filter

It is recommended to clean the HEPA filter at least once every two weeks. The cleaning cycle can be based on the usage environment and time, seriously polluted environment should be cleaned frequently.


1. Unplug the appliance and take out the HEPA filter.




2. Vacuum the dust or wipe it with a dry cloth.



3. Assemble the HEPA filter.



4. Plug in the appliance and start it.





Model No. G-Pure-25W

## FILTER REPLACEMENT


1. Filter model: G-PURE-25W FILTER



2. When the filter replacement light is on, it reminds that the HEPA filter should be replaced in time, the prompt will appear every startup.



3. Replace a new filter.



4. Long press timing button for 3s to reset the HEPA filter



Long press for 3s