

LED PENDANT FIXTURE

The product package includes the following components:

- 1 x LED Fixture
- 1 x Adjustable Power Cord (up to 15 feet)
- 2 x Drywall Anchors
- 2 x Screw Hooks
- 2 x Plastic Clamps

IMPORTANT SAFETY INSTRUCTIONS

Carefully read and understand the information on this instruction sheet before beginning assembly and installation. Failure to do so could lead to an electrical hazard.

CAUTION – TO PREVENT ELECTRICAL SHOCK.

Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Regularly check the cord and all other parts for damage. If any part is damaged the product should not be used.

Unplug the power plug when assembling. Do not disassemble the product, as the light diodes can cause damage to the eyes.

Do not touch the light source when the light is ON. Do not operate this fixture with a missing or damaged cover or housing.

Cleaning: Use a damp cloth, never use a strong cleaning agent.

THIS DEVICE IS NOT INTENDED FOR USE IN DAMP OR WET LOCATIONS. Risk of electric shock – use only for indoor and dry locations. Do not immerse in water.

1. LED Pendant Placement

The power cord length is 15 feet long. Make sure the LED Pendant Fixture can reach the wall socket.

2. Marking Holes in the Ceiling

Mark two holes to the ceiling where you are planning to hang your LED Pendant Fixture. Make the first mark on the ceiling close to the wall where the electrical outlet is located. The second mark should be the spot where the LED Pendant will be hanging.

3. Drill the Holes into the Ceiling

Drill the two 1/4" holes into the ceiling at the marked locations in step 2. Insert the two plastic drywall anchors inside the two drilled holes, then screw in the screw hooks into each anchor.



4. Hanging Your LED Pendant

Attach the cord to one of the plastic clamps and hang the clamp to the screw hook, which is farther to the wall. Make sure the height of the LED Pendant Fixture is acceptable. Then attach the other part of the cord to the second plastic clamp and hang the clamp to the screw hook closer to the wall.

5. Plug it in!

Plug the LED Pendant Fixture to the wall socket and turn on the ON/OFF switch.

Different Mounting Styles:



LIMITED WARRANTY: This product is warranted to be free from defects in workmanship and material for 3 years. If it fails to do so, please visit www.greenliteusa.com to find out how to return the fixture. Do not return this fixture to the retailer. This limited warranty does not cover fixtures subject to accident, neglect, abuse, misuse or acts of God. Replacement or refund is your sole remedy.

For all enquiries, please contact our customer service team at info@greenliteusa.com or 1-877-255-0004 from 9:00 AM to 5:00 PM EST.

www.greenliteusa.com