



LED SCONCE FIXTURE

The product package includes the following components:

• 1 x LED Fixture • 1 x Power Cord (5.9 feet long)

• 2 x Plastic Anchors

• 2 x Mounting Screws

IMPORTANT SAFETY INSTRUCTIONS

Carefully read and understand the information on this instruction sheet before beginning assembly and installation. Failure to do so could lead to an electrical hazard.

CAUTION - TO PREVENT ELECTRICAL SHOCK.

Never use with an extension cord unless plug can be fully inserted. Do not alter the plug. Regularly check the cord and all other parts for damage. If any part is damaged the product should not be used.

Unplug the power plug when assembling. Do not disassemble the product, as the light diodes can cause damage to the eyes. Do not touch the light source when the light is ON. Do not operate this fixture with a missing or damaged cover or housing. Cleaning: Use a damp cloth, never use a strong cleaning agent.

THIS DEVICE IS NOT INTENDED FOR USE IN DAMP OR WET LOCATIONS. Risk of electric shock - use only for indoor and dry locations. Do not immerse in water.

1. LED Sconce Fixture Placement

The power cord length is 5.9 feet long. Make sure the LED Sconce Fixture can reach the wall socket.

2. Marking Holes for the Mounting Plate

Mark the two drill holes on the wall with 3.15" distance apart - make sure the two drill holes are at the same level on the wall (not crooked).

3. Drilling the Holes into the Wall


Drill the two 1/4" holes in the drywall surface at the marked locations in step 2. Insert the two plastic drywall anchors inside the two drilled holes, then screw in the mounting screws into each anchor. If the mounting surface is solid wood, drill two pilot holes and screw the mounting screws into the holes directly. The distance between the flat surface of the mounting screw head and the wall surface should be between 0.08" to 0.16" to allow the LED Sconce Fixture to be hooked on them.

4. Installing the LED Sconce Fixture to the Two Mounting Screw Heads

Install the LED Sconce Fixture to the two mounting screws. Make sure that the two mounting screws goes into the two keyhole slots on the base of the LED Sconce Fixture and make sure the LED Sconce Fixture is mounted securely without moving.

5. Plug it in!

Plug the LED Sconce Fixture to the wall socket and turn on the ON/OFF switch.



LIMITED WARRANTY: This product is warranted to be free from defects in workmanship and material for 3 years. If it fails to do so, please visit www.greenliteusa.com to find out how to return the fixture. Do not return this fixture to the retailer. This limited warranty does not cover fixtures subject to accident, neglect, abuse, misuse or acts of God.

Replacement or refund is your sole remedy.

For all enquiries, please contact our customer service team at info@greenliteusa.com or 1-877-255-0004 from 9:00 AM to 5:00 PM EST.

www.greenliteusa.com